




INPUT



FOOT
SWITCH



DRIVE




CHANNEL



RHYTHM





I
•
II





TREBLE





MIDDLE



BASS



MASTER



V
•
III
•
IV

LEAD

EFFECTS

SEND

RETURN

