LITTLE AND BASTARD

POT SWITCH =	P.P = MIDDLE LEAD SCOOP
POT SWITCH =	BASS CLEAN = MIDDLE ON / OFF
PANEL SWITCH =	FAT = MIDDLE LEAD PUNCH
PANEL SWITCH =	BRIGHT LEAD SWITCH

RELAYS / only PANEL SWITCH =	R. Pump = BASS PUNCH SWITCH
RELAYS / PANEL SWITCH+FOOTSWITCH =	R.Ch. S. 1 + 2 = CH. SELECT
RELAYS SWITCH only FOOTSWITCH =	R. BOOST = BOOST M.V. LEAD