
INPUT
BUS
Reverb
Send
Return
Treble
Bass
Lead Volume
Master
Balance
FX Loop
Send BUS
Return BUS
Stand By Ein 458 Volts
Stand By Aus 438 Volts
Standby
Fuse
external internal
230 Volter 1,25 AM 1,6 AT
117Volter 2,5 AM 3,15 AT
BIAS ADJUSTMENT
DC-VOLTAGE BETWEEN
A AND C: 1,6-2,2 Volts
B AND C: 1,6-2,2 Volts
ENGL Gerätebau GmbH
328-2