

Rectifier Summary						
Type	Heater (volts)	Heater Current Requirement (amps)	Current Supplied (ma)	Voltage Drop (Volts)	approximate  voltage increase  * example: 1/2AC x 1.3 (GZ34) =  voltage to plates	Pin/ base type
5Y3	5	2	125	60	1.1	8/5T
5Y3GT	5	2	125	20	1.1	8/5T
5AR4	5	1.9	225-250	30	1.3	8/5L
5R4 GYA/GYB	5	2	250	63-67	1.1 ?	8/5T
5U4G	5	3	225	44	1.2	8/5T
5U4GA	5	3	250	44	1.2	8/5T
5U4GB	5	3	275 ?	50	1.2	8/5T
5V4	5	2	175	25	1.2	8/5L
GZ34	5	1.9	250	30	1.3	8/5L
EZ80/6V4	6.3	.6	90	22	?	9
EZ81/6CA4	6.3	1	150	28	1.3	9/9M
6X4	6.3	.36a	70	22	1.1	9/5BS
6X5	6.3	.6	70	22	1.1	8/6S
6AX5GT	6.3	1.2	125	50	1.1	8
pair of diodes  solid state					1/AC x 1.4 =	

Tube Summary usage in Guitar Amps			
Tube type	Plate voltages used in guitar amps (Typical Vdc)	Heater Current Requirement (Amps @ 6.3vdc)	Typical Current requirement per pair (push/pull) (unless otherwise noted)  (ma)
<b>6V6</b>	330v-425	.45	70
<b>6L6</b>	365v-475	.9	140
<b>EL84/6QB5</b>	250v-350	.76	90
<b>EL34/6CA7</b>	385v-475	1	120-160
<b>6AQ5</b>	250v-275	.45	80
<b>5881</b>	350v-420	.9	140
<b>6550</b>	400v-600	1.6	273
<b>12AX7</b>	130-160-200 ("typical" V1 position)  110-400 (other positions)	.3	pre-amp around 1-2  phase inverter 5-10